Please read and save these instructions. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference.

World Dryer[™] Warm Air Hair Dryer

Description

World warm air hair dryer, powered by a DC motor, delivering 1,000 Watts of drying power with variable temperature control. This ADA compliant hair dryer runs on 120 Volts AC electrical supply. Automatic operation initiates by removing the blower handle from the rest cradle and stops when returned. A 15 minute safety timer shuts the unit off automatically if the handle is not placed in the cradle. This appliance is intended for use in hair styling and drying. This hair dryer may be used in commercial and residential environments.

General Specifications

ADA Compliant

Model	Nozzle	Drying Cycle	Dimensions (W x H x D)	Weight (Lbs.)
HD3	24" Hose	Automatic	8" x10 ¹ / ₂ " x 4"	5.3 Lbs.
	Extends to 72"	W/15 minute timer		

Electrical Specifications

cULus Listed E309479

Model	Туре	Electrical Input	Amperage	Watts
HD3	Plug-in	120 VAC, 50/60 Hz	8.3	1,000

Unpacking

- Remove all packing material. Recycling is recommended.
- Carefully remove the hair dryer from the shipping carton, using care not to drop the appliance.
- Inspect carefully for any damage that may have occurred during transit.
 Check for any loose, missing or damaged parts.

General Safety Information

ADANGER Failure to unplug the unit before servicing, can result in serious injury or death from electric shock.

 Always disconnect the power source before servicing or cleaning the hair dryer.

▲ DANGER

Bypassing or damage to the appliance

leakage current interrupter (ALCI) could result in severe electrical shock and or death.

AWARNING Risk of fire, personal injury or property damage are possible if local codes, NEC codes or safety recommendations are not followed.

- Do not connect to an extension cord.
- Do not connect more than one (1) unit per 15A circuit.
- Do not exceed the combined rated load of the circuit.

ACAUTION Improper mounting of this hair dryer could result in personal injury or property damage.

 Follow the mounting recommendations in Figure 1.

Installation

- 1. Unplug unit.
- 2. Select mounting location:
- A minimum of 24" above any surface.
- Within easy reach of a 15A outlet. Do not stretch the cord and do not create a trip hazard.
- When two or more dryers are installed, they should be placed no closer than 24" (60cm) from center to center.
- Place the mounting template on the wall at the desired location. Use figure 1, as a guide. Mark the (2) mounting screw holes.
- 4. Using the supplied mounting screws and molys or a suitable alternative as required, securely attach the mounting hook and retainer to the wall.
- Align the dryer to catch the hook and push against the lower retainer until flush with the wall.
- 6. Safely route the cord and plug to the outlet and insert.
- Your dryer is now ready for use.
 If any problems are encountered, refer to the trouble shooting chart.

World[™] Warm Air Hair Dryer

Operation

- Remove handle from main unit.
 Hair dryer will start automatically
- Adjust the temperature control on the front of the dryer. Maximum heat and air flow for quick drying power. Low temperature offers gentler heat and air flow for optimum hair styling performance.
- When finished using hair dryer, replace handle securely into the cradle in front of main unit. Hair dryer will turn off automatically.

ACAUTION

As with all electrical appliances certain

precautions need to be followed to ensure safe, trouble-free use of the Hair Dryer:


DO NOT:

- Use hair dryer while bathing
- Let hair dryer operate unattended
- Immerse handle in water or other liquid
- Retrieve handle from water unless main power source is turned off
- Clean internal surfaces or components with water or other liquid
- Block air inlets or outlets when operating hair dryer
- Operate when using aerosol (spray) products
- Operate where oxygen is being used

DO NOT PERMIT CHILDREN TO USE HAIR DRYER UNATTENDED!

Maintenance

- Always keep hair dryer clean and free from dirt, lint or foreign matter. Ensure that all air inlets slots are not blocked with any debris.
- Routinely clean external surface of the hair dryer with mild soap and water.
 - (DO NOT USE DETERGENTS AS THIS MAY DAMAGE PLASTIC)



World Warm Air Hair Dryer

Troubleshooting Chart - Corrective actions must be performed by a qualified electrician.

Symptom	Possible Cause(s)	Corrective Action
Dryer will not run	No power to unit.	 Confirm that the breaker supplying the dryer is operational If the hair dryer appears to "blow" its circuit breaker supplying power, check the total load on that circuit. The hair dryer requires 8.3 amps at maximum heat.
Fan motor runs but no heat	Open thermal protector	1. The hair dryer has internal reset protection against overheating. However is the hair dryer air intake is blocked for an extended period, the internal thermal protection may cut power to the heating element permanently. This is a safety feature. Make certain that the air flow entering and exiting the hair dryer is not blocked.

LIMITED WARRANTY

World LIMITED ONE-YEAR WARRANTY. World Warm Air Hair Dryer, Model covered in this manual, is warranted by World Dryer Corporation to the original user against defects in workmanship or materials under normal use for one year after date of purchase. Any part which is determined to be defective in material or workmanship and returned to an authorized service location, as World designates, shipping costs prepaid, will be, as the exclusive remedy, repaired or replaced at World's option. For limited warranty claim procedures, see PROMPT DISPOSITION below. This limited warranty gives purchasers specific legal rights which vary from jurisdiction to jurisdiction.

LIMITATION OF LIABILITY. To the extent allowable under applicable law, World's liability for consequential and incidental damages is expressly disclaimed. World's liability in all events is limited to and shall not exceed the purchase price paid.

WARRANTY DISCLAIMER. World has made a diligent effort to provide product information and illustrate the products in this literature accurately; however, such information and illustrations are for the sole purpose of identification, and do not express or imply a warranty that the products are MERCHANTABLE, or FIT FOR A PARTICULAR PURPOSE, or that the products will necessarily conform to the illustrations or descriptions. Except as provided below, no warranty or affirmation of fact, expressed or implied, other than as stated in the "LIMITED WARRANTY" above is made or authorized by World.

PRODUCT SUITABILITY. Many jurisdictions have codes and regulations governing sales, construction, installation, and/or use of products for certain purposes, which may vary from those in neighboring areas. While **World** attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchase and use of a product, review the product applications, and all applicable national and local codes and regulations, and be sure that the product, installation, and use will comply with them.

Certain aspects of disclaimers are not applicable to consumer products; e.g., (a) some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you; (b) also, some jurisdictions do not allow a limitation on how long an implied warranty lasts, consequentially the above limitation may not apply to you; and (c) by law, during the period of this Limited Warranty, any implied warranties of implied merchantability or fitness for a particular purpose applicable to consumer products purchased by consumers, may not be excluded or otherwise disclaimed.

PROMPT DISPOSITION. World will make a good faith effort for prompt correction or other adjustment with respect to any product which proves to be defective within limited warranty. For any product believed to be defective within limited warranty, first write or call dealer from whom the product was purchased. Dealer will give additional directions. If unable to resolve satisfactorily, write to World at address below, giving dealer's name, address, date, and number of dealer's invoice, and describing the nature of the defect. Title and risk of loss pass to buyer on delivery to common carrier. If product was damaged in transit to you, file claim with carrier.

Manufactured for World Dryer Corporation, 5700 McDermott Drive, Berkeley, Illinois 60163 U.S.A.